User Manual



# WINIX AIR PURIFIER





• The product warranty is printed on the back of this guide, so please keep it in a safe place for future use.

# CONTENTS

3-STAGE AIR PURIFICATION 3
CONTROLS 4
WHERE TO USE 5
INSTALLING FILTERS 6
SAFETY AND CAUTIONS 10
INITIAL OPERATION 11
AUTO & SLEEP 12
MANUAL & AIR QUALITY INDICATOR
FILTER CARE ······14
PARTICLE SENSOR CARE 16
CLEANING CARE 17
FREQUENTLY ASKED QUESTIONS 18
UNIT SPECIFICATIONS 20
PRODUCT WARRANTY 21
French 23
Spanish · · · · · · · · · · · · · · · · · · ·
German · · · · · · · · · · · · · · · · · · ·
Italian · · · · · · · · · · · · 89
Dutch
Polish · · · · · · · · · · · · · · · · · · ·

► This product is suitable for 220 - 240V~, 50/60Hz only.

### **3-STAGE AIR PURIFICATION**



### CONTROLS





- ① Fan Speed Indicator Indicates the current fan speed.
- (2) Change Filter Indicator LED light indicates when it is time to change the filter.
- ③ Reset Button After replacing a filter, press the RESET button for at least 5 seconds.
- Air Quality Indicator
   Color-coded LED indicates one of three levels of air quality.
- ⑤ Power Button Turns the unit on or off.
- (6) Fan Speed Button (UP/DOWN) Enables Manual operation of the unit. Press to cycle through and set the desired fan speed (Low, Medium, High).
- C Light Sensor Detects the amount of ambient light within the environment, to adjust the brightness of the LED indicators.

# WHERE TO USE

Allow 30 - 45 cm. of space between TVs, radios, and other electronic products electromagnetic interference from certain electronics may cause product malfunction.

Place indoors away from direct sun light direct exposure may cause product malfunction or failure.

Only place on hard, flat surfaces

flimsy or slanted surfaces may result in abnormal noise and vibrations.



Follow these instructions to reduce the risk of serious injury or death and to reduce risk of damaging the unit.



X This unit is not intended to be used to preserve documents or in art conservation.

This product comes with all required filters. The protective plastic wrap must be removed from the filter before use.

- \* Operating the unit without removing the plastic wrap may result in product failure.
- X Unplug and make sure the unit is turned off before installing filter.
  - ① Remove the front panel by pressing down on both edges of the front and gently pulling it toward the front.
- ② Press on the Pre-filter tabs near the top of the filter, release and remove.

③ Remove the carbon filter from the filter case.



- ④ Remove filters from protective plastic wrap.
  - Operating the unit without removing filters from plastic wrap may cause abnormal noise, deformation, or fire as a result of overheating.
- (5) After removing the packing vinyl of the filter, insert the carbon filter into the filter case.

6 Pull out the True HEPA filter.

 $\textcircled{O}\;$  Remove the filter case, then remove the True HEPA filter.









⑧ Ture HEPA filter → Filter case in order, pushing it in close to the back of the product.



④ After inserting both ends of the fabric pre filter, press both sides of the top to close it.



When to service and replace filter:

Filter	Indicator Light	When to service	When to replace
1 Fabric filter	none	Clean once every 14 days	-
2 Carbon filter	none	Can NOT be WASHED	Replace every 3 months
<b>3</b> True HEPA filter	Check Filter		Lasts up to 6~12 months

% Intervals between filter replacement may vary depending on environment.

- \* For optimal use, Fabric filter can be cleaned once every 14 days which can extend the life of other filters.
- X Use a vacuum cleaner or soft brush to lightly remove dust from the fabric filter. If deeper cleaning is required, place the filter under running water or wash it with synthetic detergent.

#### To purchase replacement Winix filters:

contact your local dealer Filter R: Carbon filter and Ture HEPA filter



# SAFETY AND CAUTIONS

Before operating this equipment, carefully read and follow these safety cautions

#### Ensure filters are inserted before running unit

running unit without filters can shorten the units life and cause electric shock or injury.

Be sure foreign objects are NOT inserted into the vents on the unit objects can include pins, rods, and coins.

#### Do not touch any part of the interior of the unit with wet hands the high voltage may cause electric shock.

#### Ensure unit intake and outlet vents do not become blocked

blockage may lead to increased internal termperatures causing product failure and derformation.

#### Do not use the unit as a step stool or place heavy objects on it

personal injury may occur or product failure and deformation.



they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

X Children should be supervised to ensure that they do not play with the appliance.

#### **INITIAL OPERATION**

① Insert the power cord into an electrical outlet.

2 Press the 'Power' button.





# 

 During the first 30 seconds of power up, the Air Quality Indicator will cycle through Blue, Amber and Red colors. The Particle Sensors take approximately 30 seconds to gauge the air quality in the environment, after which normal operation will begin.

# ③ By default, when the unit first powers on, the mode will be set to Auto enabled.

• When in Auto mode, the fan speed will be automatically adjusted according to the environments air quality.



#### **NOTE**

- In Auto mode, as the indoor air quality improves, the fan speed will automatically be reduced to Low.
- When the unit is running, you may hear a chirping or buzzing sound.

#### **AUTO & SLEEP**

#### 1. Auto Mode

Enables auto operation based on the unit's air quality Particle Sensor.

- ① Press the Fan speed (UP/DOWN) button to select Auto mode.
  - The LED 'Auto' light will indicate when Auto mode is activated, and operation will begin.



• When in Auto mode the fan speed is automatically adjusted according to the indoor air quality. As the indoor air quality improves, the fan speed will automatically be reduced. If the indoor air quality decreases, the fan speed will automatically increase.

#### 2. Sleep Mode

- ① Press the Fan speed (UP/DOWN) button to select Sleep mode.
  - The LED 'Sleep' light will indicate when Sleep mode is activated, and operation will begin.



### 

- When Sleep mode is selected, the fan speed is automatically set to Low. The fan speed can be manually changed by pressing the Fan Speed button, changing the unit into manual mode.
- When Sleep Mode is activated, the Air Quality Indicator LED light is disabled.

# MANUAL & AIR QUALITY INDICATOR

#### 3. Manual Mode (setting fan speed)

Users can optative to manually set the fan speed to Low, Medium, High.

① Press the Fan Speed button to set the desired fan speed.



When Manual Mode is selected, Auto Mode is automatically disabled.

#### 4. Air Quality Indicator

When on, the LED light will indicate the current indoor air quality according to three levels : BLUE (good), AMBER (fair), RED (poor).



• Air quality level is displayed on the indicator, based on the Particle Sensors. Depending on the immediate environment, the indicator may change frequently in color or stay the same for lengthy periods of time.

# **FILTER CARE**

#### **1. About The Filters**

When the Check Filter indicator LED is on, it is time to replace the True HEPA filter.

Filter	Indicator Light	When to service	When to replace
1 Fabric filter	none	Clean once every 14 days	-
2 Carbon filter	none	Can NOT be WASHED	Replace every 3 months
<b>3</b> True HEPA filter	Check Filter		Lasts up to 6~12 months

X Intervals between filter replacement may vary depending on environment.

- \* For optimal use, Fabric filter can be cleaned once every 14 days which can extend the life of other filters.
- ※ Use a vacuum cleaner or soft brush to lightly remove dust from the fabric filter. If deeper cleaning is required, place the filter under running water or wash it with synthetic detergent.

#### To purchase replacement Winix filters:

contact your local dealer Filter R: Carbon filter and Ture HEPA filter





- The lifetime of a Filter is depending on the level of pollutants in the air. The more dust present in the environment, the more dust accumulates in the filters, shortening the life.
- If the filters are heavily soiled or have a bad odour, or if the fan strength is significantly weakened, replace filters even if the Change Filter indicator has not yet turned on.

# **FILTER CARE**

#### 2. Resetting The Unit

 After replacing the filters, turn the power back on and then use a thin object, such as a paper clip, to press the RESET switch for 5 seconds.



#### 3. Cleaning the Fabric Pre-filter

Intervals between filter cleaning may vary depending on the air quality.

 Use a light brush to clean if the filter's pattern can be seen. If the filter's pattern can be seen clearly, we recommend using the filter only after washing. This signals that a lot of dust has accumulated.



- ② We recommend the use of a vacuum cleaner to remove light dust buildup.
- ③ If there is a lot of dust, we recommend hand-washing the filter under running water with synthetic detergent. However, the microfiber in the filter may be damaged if a brush is used during hand-washing.
  - Do not use detergent or soap.
  - Allow the filter to dry for 24 hours or more before using.
- (4) When using a washing machine, we recommend washing the filter by itself to prevent other items from becoming discolored or contaminated.

\* If the Fabric Pre-filter becomes damaged or in any way needs replacement: Please contact your local dealer

⚠️ NOTICE	<ul> <li>Do not use benzene, alcohol, or other volatile fluids, which may cause damage or discoloration.</li> <li>The Fabric Pre-filter is reusable after cleaning, ensuring it is completely dry.</li> <li>If the fabric material is full of dust in some places, we recommend lightly scrubbing the filter with water or neutral soap using a soft cloth or sponge before allowing it to completely dry.</li> <li>Hand-washing of the filter will allow it to be used for a longer period of time.</li> <li>When cleaning or washing the fabric filter, we recommend that it first be removed from the unit.</li> <li>Do not use hot water over 40°C or volatile fluids such as paint thinner.</li> <li>After washing the filter, allow it to dry completely in a well ventilated area. Otherwise, it may develop a bad odour.</li> </ul>

# PARTICLE SENSOR CARE

#### **Particle Sensors Care**

For optimal performance of the Particle Sensor, which detects airborne dust and ultrafine particles, clean it every two months. Clean it more frequently when the unit is running in a place with high dust levels.

① Open the Particle Sensor cover.



- ② Use a damp cotton swab to wipe the lens and intake area of the Particle Sensor.
  - To clean the sensor area, use only water. Do not use volatile substances such as alcohol or acetone



③ Wipe away any remaining moisture with a dry cotton swab.



- ④ Close the Particle Sensor cover.
  - The Particle Sensors cover may be cleaned using a vacuum cleaner



# **CLEANING CARE**

#### 1. Cleaning the Exterior & Interior

- Wipe with a soft damp cloth using room temperature water. Afterwards, wipe it down with a clean dry cloth.
  - To keep unit in peak condition, clean every 1-2 months.



- ② Take off the fabric pre-filter that is fastened to the front panel.
  - The fabric pre filter is secured by the 12 hooks on the back of the front panel.



- ③ Open the front panel and clean the interior with a vacuum cleaner.
  - For optimal performance, clean every 1-2 months.



	NOTICE
--	--------

- When cleaning the unit, always unplug the power cord first and then wait until the unit has cooled down.
- Never disassemble, repair, or modify this unit yourself.
- Do not use flammable sprays or liquid detergents.
- Do not allow children to clean or maintain the unit.
- Before cleaning or maintaining, ensure unit is unplugged.

# FREQUENTLY ASKED QUESTIONS

Problem	Check / Actions to take	
lt does not turn on at all.	<ul> <li>Is the plug securely attached to the outlet? <ul> <li>Make sure the outlet has power going to it, and ensure the plug is secured.</li> </ul> </li> <li>Is there a power outage? <ul> <li>Check to see if other lights and electrical equipment are working and try again.</li> </ul> </li> </ul>	
lt doesn't work in Auto Mode.	<ul> <li>Has Auto Mode been selected? <ul> <li>Press the Mode button until Auto Mode is selected.</li> </ul> </li> <li>Is the sensor blocked or clogged? <ul> <li>Wipe Odour Sensor with wet cloth, then dry.</li> </ul> </li> </ul>	
It vibrates and makes a lot of noise.	<ul> <li>Is it running on a slanted or uneven surface?</li> <li>Move the unit to a hard, flat, even area of the floor.</li> </ul>	
The power plug and outlet feel hot.	<ul> <li>Is the plug securely plugged in?</li> <li>Make sure the plug is properly plugged into the outlet.</li> </ul>	

# FREQUENTLY ASKED QUESTIONS

Problem	Check / Actions to take	
There is a strange smell.	<ul> <li>Is it being used in a place with a lot of smoke, dust, or odours?</li> <li>Clean the air intakes on either side and clean the Fabric filter.</li> <li>Clean or change the filter.</li> </ul>	
The fan strength is weak. The unit is not purifying the air.	<ul> <li>Is the Check Filter indicator light on?</li> <li>Change the filters as required.</li> </ul>	
<ul> <li>Is the Light Sensor blocked by debris?</li> <li>When Auto Mode is on, Sleep Mode is automatically activated when the Light Sensor detects that the room is dark.</li> </ul>		

# UNIT SPECIFICATIONS

Model Name	ZERO-N (AZNU230-HWE, AZNU230-HWB)	
Power Voltage	AC 220 - 240 V, 50 / 60 Hz	
Power Rate	30 W	
Max Room Capacity	45 m <sup>2</sup>	
Dimensions	350 mm(W) x 207 mm(D) x 470 mm(H)	
Weight	6.2 kg	
Replacement Filter	Filter R / item : 1712-0088-00	

X The exterior, design and product specifications may be changed without prior notice to improve product performance.

# **PRODUCT WARRANTY**

#### The terms of the warranty are as follows.

- 1 This product is manufactured under stringent quality control and inspections.
- 2 Warranty void if product failure is a result of negligence or misuse by the consumer, shipping and service fees may be incurred even during the warranty period.
- 3 The warranty must be presented upon bringing the product for service.
- 4 Please keep the warranty page of the manual on a safe place, as it cannot be reissued.
- 5 This warranty is only valid in Europe.

Product Name		Air Purifier
Model Name		ZERO-N (AZNU230-HWE, AZNU230-HWB)
Purcha	se Date	
Warrant	y period	Two (2) years
Place of	purchase	
Place of pu	ırchase Tel.	
	Address	
Customer	Name	
	Tel.	

X After purchase, be sure to complete all of the above information.



CE





2610-0174-00 Rev.00

O Contact your local dealer for product related inquiries and customer service

WWW.WINIX.COM/EU